



**PARAGON**

## DRAIN KIT

This kit includes (2) male fittings and (2) female fittings

### Garment

1. Connect female fittings to the male fittings on the garment.
2. Set air compressor to a maximum of 40-50 psi. Insert air compressor hose, with a small nozzle attachment, into the tubing attached to the female connector. Cycle air compressor for a maximum of 10-15 seconds.

### Water Hose

1. Connect female fittings to the male fittings on the hose and connect male fittings to the female fittings on the hose.
2. Set air compressor to a maximum of 40-50 psi. Insert air compressor hose, with a small nozzle attachment, into the tubing attached to the female connector. Cycle air compressor for a maximum of 10-15 seconds.

1146 Carding Machine Road  
865.643.8700

Loudon, Tennessee 37774  
[www.paragonproinc.com](http://www.paragonproinc.com)



**PARAGON**

## DRAIN KIT

This kit includes (2) male fittings and (2) female fittings

### Garment

1. Connect female fittings to the male fittings on the garment.
2. Set air compressor to a maximum of 40-50 psi. Insert air compressor hose, with a small nozzle attachment, into the tubing attached to the female connector. Cycle air compressor for a maximum of 10-15 seconds.

### Water Hose

1. Connect female fittings to the male fittings on the hose and connect male fittings to the female fittings on the hose.
2. Set air compressor to a maximum of 40-50 psi. Insert air compressor hose, with a small nozzle attachment, into the tubing attached to the female connector. Cycle air compressor for a maximum of 10-15 seconds.

1146 Carding Machine Road  
865.643.8700

Loudon, Tennessee 37774  
[www.paragonproinc.com](http://www.paragonproinc.com)